

MODIFIEDS, SPORT MODS, STOCK CARS & ECO MODS

YOUR TRANSPONDER LOCATIONS HAVE CHANGED

MODIFIED – TRANSPONDER MUST BE MOUNTED ON BOTTOM RT REAR OF MOTOR PLATE

SPORT MOD - TRANSPONDER MUST BE MOUNTED ON BOTTOM RT REAR OF MOTOR PLATE

STOCK CAR – TRANSPONDER MUST BE MOUNTED TO BOTTOM RT SIDE OF FIREWALL

ECO MOD - TRANSPONDER MUST BE MOUNTED ON BOTTOM RT REAR OF MOTOR PLATE